

DURATAC™ FASTILES

Installation Instructions

Installation of Duratac Fastiles

Do not install Duratac Fastiles directly to surface if; On Asphalt, exposed aggregate concrete or concrete that is less than 14 days old. In this instance use Duratac Primer. Please see below instructions for the use of Duratac Primer

1. Ensure surface is dry and free from any dust. Acetone can be used to rub the surface down to ensure a clean surface. Ensure excess acetone has been removed.
2. Peel off backing on Duratac Fastile and place in position.

Installation of Tactiles using Duratac Primer

1. Ensure area is free from any dust.
2. Using Masking Tape, mask off the area where primer is required.
3. Paint on Primer using a paint brush.
4. Once Duratac Primer is dry, remove masking tape. Proceed to install Duratac Fastiles as per instructions above.

Tips on successful Installations

Ensure water does not pool behind Duratac Fastiles. This can lead to pedestrians getting wet feet and the Duratac Fastiles lifting over time.

Ways to ensure this does not happen:

- Leave a gap between wall/kerb and Duratac Fastiles
- If length of area of Tactiles is over 3m long, either create a break at a handrail (Tactiles are only required to cover the width of travel or if there is no handrail within 3m, leave a 5mm gap between Duratac Fastiles every 3m.)