

PRODUCT DATA SHEET

Low Traffic

Polyrib

- Popular ribbed construction traps dirt and moisture in recessed channels below shoe level.
- Durable polypropylene needlepunch fibres.
- Slip resistant vinyl backing with 25mm borders.
- · Stain and fade resistant.
- · Easy to clean.





	Code	Size & Thickness	Installation Note
	5006090	600 x 900 mm	Most commonly
	50090150	900 x 1500 mm	Ensure the recess
	500120180	1200 x 1800 mm	size of the recess (or similar). Use S over both surface
	50090C	900 mm wide runner	
	500120C	1200 mm wide runner	on top of the adh
	500180C	1800 mm wide runner	even pressure over trimmed correctly
	50090C	900 mm x 18.2m roll	
	500120C	1200 mm x 18.2m roll	
	500180C	1800 mm x 18.2m roll	
		Thickness: 7 mm	

Most commonly loose lay – can be installed in a recess though Ensure the recess is clean and free of debris Cut the mat to the size of the recess using a trimming knife, such as a Stanley knife (or similar). Use Sikabond 105 Contact Fix and spread evenly over both surfaces either by sprayer or trowel. Place the mat on top of the adhesive and use a vinyl roller (or similar) to apply even pressure over the surface of the mat. Ensure the mat is trimmed correctly to the area to prevent tripping hazards

Colours



Applications

Residential Buildings, Light Commercial Buildings, Educational Institutions, Office Areas, Shopping Centres.

- P 1800 621 103
- sales@sterlingsupplies.com.au
- www.sterlingsupplies.com.au

