



STERLING
SUPPLIES

CLEANING GUIDE

CARPEX CARBORUNDUM CUSHION BACK

Daily Maintenance of Carpex Carborundum Cushion Back is recommended, best practice is to brush thoroughly with a soft bristle broom to remove any dirt or grit. Also dirt can be rinsed with clean warm water.

To keep product in good condition so that warranty is not voided, the following is recommended on a 1 – 2 month basis:

- Remove any dirt and grit with a stiff bristle broom
- In external applications wash with clean warm water
- Add a PH neutral based detergent to warm-hot water in a bucket
- Dip stiff bristle broom into bucket of detergent then scrub the surfaces, to remove dirt and grime.
- Rinse off with clean water, ensuring there is no detergent or soap suds left on product.

DO NOT

- Do not steam clean, when products are installed into carpet.
- Do not use cleaning chemicals that contain chlorides or abrasives.
- Do not clean with wire brush.

Please Note:

To prevent the voiding of any applicable guarantees, careful and routine maintenance is required. This information is based on our prior knowledge and the outcomes of thorough testing. Different site characteristics and usage patterns could have an impact on the practical application. Before performing any cleaning or maintenance, it is always advisable to seek specialised guidance from a trustworthy cleaning professional. The information provided here is just meant to serve as a general guide.

